





CaptainOring.com
Nova Liberty
(.177, .22)
O-Ring Replacement Guide


O-Ring Sizes




Air Reservoir
Front Assembly




Air Reservoir
Rear Plug



Probe Assembly




Trigger/Air Release Assembly





CaptainOring.com
Nova Liberty
(.177, .22)
O-Ring Replacement Guide

Pressure Relief Valve Assembly



Inner Barrel Assembly



Regulator Chamber



Fill Probe

